

# Anleitung – einlernbarer VIP Schlauch / Instruction manual – teach-in process remote control hose VIP

Zum Einlernen des Gerätes folgende Tastenkombinationen drücken:

- Stecken Sie den VIP Saugschlauch in eine Saugsteckdose.
- Die ON/OFF Taste und die + Taste am Schlauch gleichzeitig drücken bis das orangene Symbol oder die grünen Symbole des Schlauches blinken.
- Sofort einmal kurz die ON/OFF Taste drücken, um den Einlernvorgang zu starten (der Zentralstaubsauger springt an und die Saugleistungsstufen werden für einige Sekunden gefahren).
- Wenn der Einlernvorgang erfolgreich war, blinken die drei grünen Symbole.

Please push the following buttons to start the teach-in process:

- Insert the VIP hose into a inlet valve.
- Push the ON/OFF and + button on the hose at the same time until the orange or the green symbols are blinking.
- Push the ON/OFF button immediately in order to start the teach-in process (the central vacuum cleaner starts and begins to operate for a few seconds).
- If the teach-in process was successful the three green lights will start to blink.